






1. The top and bottom sides of the inlet must be accessible for proper installation of the baffle clips.
2. At opposite corners of the inlet housing, locate and drill a 3/16-in hole 1-in away from the edge of the baffle as shown in Figure 1.
3. Install a rivet, rivet washer and baffle clip on the housing as shown in Figure 2. Use a rivet gun to set the rivet. Repeat installation at the opposite corner.
4. Rotate the clips, as desired, to either hold the baffle closed or to allow the baffle to open freely.
5. **Warning:** When the ceiling inlets are held closed with the baffle closure kit, the occupants in the room may experience health hazards or death unless adequate inlet area into the room is provided from another source.



**Parts List**

<u>Part Number</u>	<u>Description</u>	<u>Quantity</u>
SV-CI1503	Baffle Clip Aluminum	2 ea
RFR-0823	Pop Rivet 3/16 Flange Aluminum	2 ea
RFW-0922	Rivet Washer 3/16 Aluminum	2 ea